



# LITE

## Dust Free Powder Bleach - up to 7 levels of lift.

Lite is a high performance powder bleach suitable for all types of bleaching techniques. The gentle formula can be used with 3%(10vol), 6%(20vol), 9%(30vol) and 12%(40vol) developers to achieve high lifting power with optimum hair condition. Lite contains guar gum to help protect the scalp, and hydrolysed silk to protect the cuticle, preventing damage. Lite is available in both blue and white powder. For best results use Affinage Crème Developer. For on scalp use, we recommend that only 3%(10vol) or 6%(20vol) is used.

### Mixing Instructions

Mix 1 scoop of Lite powder with 2 scoops of your chosen Affinage Crème Developer. You may vary the consistency by adding slightly different amounts of developer according to the technique you wish to use, i.e. full head, foil or cap highlights, etc.

### Application

Do not wash the hair before lightening.

Full Head application, Lite should be applied to the middle lengths and ends first and then to roots.

On re-growth - apply Lite to the roots only.

For on scalp application DO NOT COVER. DO NOT USE HEAT.

### Development Time

Lite is active for up to 60 minutes.

For very dark hair processing time may take up to 50 minutes. Light bases may require only a short processing time. Check frequently. When the required lift is achieved rinse thoroughly and gently shampoo the hair.

### Remember

Resistant hair will need a longer development time than porous hair. Always check development of Lite during processing. When the required lift is achieved rinse thoroughly and gently shampoo the hair.

### Highlighting

Do not wash the hair before application. Use desired method of highlighting, i.e. foil, meches, highlighting cap, etc. Apply Lite liberally to the hair. Check development time frequently.

### Important

DO NOT apply to the scalp if there are any abrasions or signs of irritation.

DO NOT mix the product in a confined space and avoid inhaling the powder.

If the product gets into the eyes wash immediately with cold water. Always use rubber gloves.